



BONN / BISTRO



Teller flach rund Fahne

Plate flat round with rim
Assiette plate ronde avec aile
Plato llano redondo con ala

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Teller flach rund Fahne 16cm	0006 54 0016 12 000000		160 (6.3)	16	225	4,30	5,59	6,88	8,17	9,46
Teller flach rund Fahne 19cm	0006 54 0019 12 000000		189 (7.44)	17	315	6,82	8,87	10,91	12,96	15,00
Teller flach rund Fahne 20cm	0006 54 0020 12 000000		202 (7.95)	19	375	7,18	9,33	11,49	13,64	15,80
Teller flach rund Fahne 23cm	0006 54 0023 12 000000		231 (9.09)	21	550	9,67	12,57	15,47	18,37	21,27
Teller flach rund Fahne 24cm	0006 54 0024 12 000000		241 (9.49)	21	580	10,21	13,27	16,34	19,40	22,46
Teller flach rund Fahne 25cm	0006 54 0025 12 000000		258 (10.16)	23	700	10,75	13,98	17,20	20,43	23,65
Teller flach rund Fahne 27cm	0006 54 0027 12 000000		272 (10.71)	27	760	12,90	16,77	20,64	24,51	28,38
Teller flach rund Fahne 30cm	0006 54 0030 12 000000		302 (11.89)	26	1070	16,12	20,96	25,79	30,63	35,46



Teller halbtief rund Fahne

Plate half-deep round with rim
Assiette mi-creuse ronde à bord
Plato semihondo redondo con ala

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Teller halbtief rund Fahne 19cm	0006 54 0119 12 000000	0.25 (8.45)	191 (7.52)	32	340	7,18	9,33	11,49	13,64	15,80



Teller tief rund Fahne

Plate deep round with rim
Assiette creuse ronde avec aile
Plato hondo redondo con ala

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Teller tief rund Fahne 23cm	0006 54 0123 12 000000	0.32 (10.82)	230 (9.06)	31	525	10,21	13,27	16,34	19,40	22,46



Platte oval

Platter oval
Plat oval
Fuente ovalada

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Platte oval 23x16cm	0006 54 2223 12 000000		232 x 158 (9.13 x 6.22)	23	360	13,94	18,12	22,30	26,49	30,67
Platte oval 26x18cm	0006 54 2226 12 000000		262 x 181 (10.31 x 7.13)	28	530	16,46	21,40	26,34	31,27	36,21
Platte oval 29x20cm	0006 54 2229 12 000000		291 x 204 (11.46 x 8.03)	29	700	19,36	25,17	30,98	36,78	42,59
Platte oval 32x23cm	0006 54 2232 12 000000		323 x 228 (12.72 x 8.98)	33	850	22,26	28,94	35,62	42,29	48,97
Platte oval 37x27cm	0006 54 2237 12 000000		372 x 265 (14.65 x 10.43)	40	1360	27,10	35,23	43,36	51,49	59,62



Suppenobertasse 0.30l

Creamsoup cup
Tasse à soupe
Taza para sopa



Kombi-Untertasse rund 16cm

Combi saucer round
Soucoupe combi ronde
Platillo combinable redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Suppenobertasse 0.30l	0006 54 2780 12 000000	0.33 (11.16)	114 (4.49)	54	255	8,65	11,25	13,84	16,44	19,03
Kombi-Untertasse rund 16cm	0006 54 6945 12 000000		156 (6.14)	25	230	4,30	5,59	6,88	8,17	9,46

BONN / BISTRO



Obertasse 0.09l

Cup
Tasse
Taza



Obertasse 0.09l

Cup
Tasse
Taza



Untertasse rund 11cm

Saucer round
Soucoupe ronde
Platillo redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Obertasse 0.09l	0006 27 5359 12 000000	0.09 (3.04)	62 (2.44)	61	110	5,88	7,64	9,41	11,17	12,94
Obertasse 0.09l	0006 27 5159 12 000000	0.09 (3.04)	71 (2.8)	43	80	5,29	6,88	8,46	10,05	11,64
Untertasse rund 11cm	0006 54 6909 12 000000		113 (4.45)	20	100	3,23	4,20	5,17	6,14	7,11



Obertasse 0.18l

Cup
Tasse
Taza



Untertasse rund 14cm

Saucer round
Soucoupe ronde
Platillo redondo



Kombi-Untertasse rund 16cm

Combi saucer round
Soucoupe combi ronde
Platillo combinable redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Obertasse 0.18l	0006 27 5168 12 000000	0.19 (6.42)	90 (3.54)	54	175	6,45	8,39	10,32	12,26	14,19
Untertasse rund 14cm	0006 54 6920 12 000000		141 (5.55)	23	192	3,87	5,03	6,19	7,35	8,51
Kombi-Untertasse rund 16cm	0006 54 6945 12 000000		156 (6.14)	25	230	4,30	5,59	6,88	8,17	9,46



Obertasse 0.25l

Cup
Tasse
Taza



Obertasse 0.35l

Cup
Tasse
Taza



Obertasse 0.45l

Cup
Tasse
Taza



Kombi-Untertasse rund 16cm

Combi saucer round
Soucoupe combi ronde
Platillo combinable redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Obertasse 0.25l	0006 27 5175 12 000000	0.25 (8.45)	100 (3.94)	58	200	7,36	9,57	11,78	13,98	16,19
Obertasse 0.35l	0006 27 5285 12 000000	0.35 (11.83)	107 (4.21)	67	225	8,65	11,25	13,84	16,44	19,03
Obertasse 0.45l	0006 27 5195 12 000000	0.45 (15.22)	118 (4.65)	73	280	9,94	12,92	15,90	18,89	21,87
Kombi-Untertasse rund 16cm	0006 54 6945 12 000000		156 (6.14)	25	230	4,30	5,59	6,88	8,17	9,46



Obertasse 0.22l

Cup
Tasse
Taza



Untertasse rund 14cm

Saucer round
Soucoupe ronde
Platillo redondo



Kombi-Untertasse rund 16cm

Combi saucer round
Soucoupe combi ronde
Platillo combinable redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Obertasse 0.22l	0006 27 5372 12 000000	0.23 (7.78)	85 (3.35)	80	165	7,74	10,06	12,38	14,71	17,03
Untertasse rund 14cm	0006 54 6920 12 000000		141 (5.55)	23	192	3,87	5,03	6,19	7,35	8,51
Kombi-Untertasse rund 16cm	0006 54 6945 12 000000		156 (6.14)	25	230	4,30	5,59	6,88	8,17	9,46

BONN / BISTRO



Obertasse 0.25l
Cup
Tasse
Taza



Kombi-Untertasse rund 16cm
Combi saucer round
Soucoupe combi ronde
Platillo combinable redondo

#										
Art.-Nr. (Art.No.)		Ltr. (fl.oz)	mm (inch)	mm	Gramm	Standard	Light	Basic	Basic+	Exclusive
Obertasse 0.25l	0006 27 5375 12 000000	0.26 (8.79)	90 (3.54)	81	190	8,17	10,62	13,07	15,52	17,97
Kombi-Untertasse rund 16cm	0006 54 6945 12 000000		156 (6.14)	25	230	4,30	5,59	6,88	8,17	9,46



Becher 0.25l
Mug
Gobelet
Vaso



Untertasse rund 15cm
Saucer round
Soucoupe ronde
Platillo redondo



Becher 0.32l
Mug
Gobelet
Vaso



Kombi-Untertasse rund 16cm
Combi saucer round
Soucoupe combi ronde
Platillo combinable redondo

	# Art.-Nr. (Art.No.)	 Ltr. (fl.oz)	 mm (inch)	 mm	 Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Becher 0.25l	0006 27 5627 12 000000	0.25 (8.45)	77 (3.03)	98	260	7,36	9,57	11,78	13,98	16,19
Untertasse rund 15cm	0006 54 6925 12 000000		151 (5.94)	26	200	4,09	5,32	6,54	7,77	9,00
Becher 0.32l	0006 54 5632 12 000000	0.32 (10.82)	88 (3.46)	94	320	8,26	10,74	13,22	15,69	18,17
Kombi-Untertasse rund 16cm	0006 54 6945 12 000000		156 (6.14)	25	230	4,30	5,59	6,88	8,17	9,46



Schälchen rund 8cm/0.07l

Small dish round

Petit bol rond

Recipiente redondo

#										
Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm		Standard	Light	Basic	Basic+	Exclusive
Schälchen rund 8cm/0.07l	0.06 (2.03)	82 (3.23)	25	90		2,74	3,56	4,38	5,21	6,03



Schale rund
 Bowl round
 Bol rond
 Bowl redondo



Schüssel rund
 Bowl round
 Saladier rond
 Bol redondo

#	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
Art.-Nr. (Art.No.)					Standard	Light	Basic	Basic+	Exclusive
Schale rund 12cm/0.36l	0.36 (12.17)	121 (4.76)	55	215	8,89	11,56	14,22	16,89	19,56
Schüssel rund 15cm/0.65l	0.65 (21.98)	149 (5.87)	64	390	13,19	17,15	21,10	25,06	29,02
Schüssel rund 17cm/0.85l	0.85 (28.74)	172 (6.77)	65	500	16,06	20,88	25,70	30,51	35,33
Schüssel rund 20cm/1.24l	1.24 (41.93)	203 (7.99)	65	700	21,65	28,15	34,64	41,14	47,63

BONN / BISTRO



Schale oval 11x8cm/0.08l

Dish oval
Bol oval
Bowl ovalada

#										
Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm		Standard	Light	Basic	Basic+	Exclusive
Schale oval 11x8cm/0.08l	0.08 (2.71)	110 x 80 (4.33 x 3.15)	23	115		5,57	7,24	8,91	10,58	12,25



Kaffeekanne Komplett 0.30l
Coffee pot
Cafetière
Cafetera



Kaffeekanne Unterteil 0.30l
Coffee pot
Cafetière
Cafetera



Kaffeekanne Deckel
Coffee pot
Cafetière
Cafetera

#										
Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm		Euro				
Kaffeekanne Komplett 0.30l	0006 54 4130 13 000000	0.30 (10.14)	135 (5.31)	119	330	Standard 19,34	Light 25,14	Basic 30,94	Basic+ 36,75	Exclusive 42,55
Kaffeekanne Unterteil 0.30l	0006 54 4131 12 000000	0.30 (10.14)	135 (5.31)	100	280	14,33	18,63	22,93	27,23	31,53
Kaffeekanne Deckel	0006 54 4132 12 000000		57 (2.24)	33	50	5,01	6,51	8,02	9,52	11,02



Teekanne Komplett 0.40l

Teapot

Théière

Tetera



Teekanne Unterteil 0.40l

Teapot

Théière

Tetera



Teekanne Deckel

Teapot

Théière

Tetera

#										
Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm		Euro				
						Standard	Light	Basic	Basic+	Exclusive
Teekanne Komplett 0.40l	0006 54 4340 13 000000	0.35 (11.83)	160 (6.3)	108	430	23,21	30,17	37,14	44,10	51,06
Teekanne Unterteil 0.40l	0006 54 4341 12 000000	0.35 (11.83)	160 (6.3)	85	330	17,19	22,35	27,50	32,66	37,82
Teekanne Deckel	0006 54 4342 12 000000		76 (2.99)	37	100	6,02	7,83	9,63	11,44	13,24



Gießer

Creamer

Crémier

Jarra

#										
Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm					Euro	
					Standard	Light	Basic	Basic+	Exclusive	
Gießer 0.05l	0006 54 4705 12 000000	0.05 (1.69)	77 (3.03)	55	75	7,16	9,31	11,46	13,60	15,75
Gießer 0.10l	0006 54 4710 12 000000	0.09 (3.04)	95 (3.74)	68	115	8,60	11,18	13,76	16,34	18,92
Gießer 0.15l	0006 54 4715 12 000000	0.14 (4.73)	105 (4.13)	79	150	10,03	13,04	16,05	19,06	22,07
Gießer 0.30l	0006 54 4730 12 000000	0.30 (10.14)	132 (5.2)	101	250	14,33	18,63	22,93	27,23	31,53
Gießer 1.70l	0006 54 4817 12 000000	1.70 (57.48)	117 (4.61)	174	1100	54,45	70,79	87,12	103,46	119,79



Sauciere

Sauce boat

Saucière

Salsera

#									
Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Standard	Light	Basic	Basic+	Exclusive
Sauciere 0.05l	0006 54 3805 12 000000	0.05 (1.69)	101 (3.98)	48 80	7,16	9,31	11,46	13,60	15,75
Sauciere 0.10l	0006 54 3810 12 000000	0.10 (3.38)	131 (5.16)	55 150	8,60	11,18	13,76	16,34	18,92
Sauciere 0.20l	0006 54 3820 12 000000	0.20 (6.76)	164 (6.46)	74 315	11,46	14,90	18,34	21,77	25,21
Sauciere 0.35l	0006 54 3835 12 000000	0.35 (11.83)	197 (7.76)	88 470	15,76	20,49	25,22	29,94	34,67

BONN / BISTRO



Zuckerdose Komplett 0.25l
 Sugar bowl
 Sucrier
 Azucarero



Zuckerdose Unterteil 0.25l
 Sugar bowl
 Sucrier
 Azucarero



Zuckerdose Deckel
 Sugar bowl
 Sucrier
 Azucarero

	#									
	Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm					Euro
Zuckerdose Komplett 0.25l*	0006 54 4925 13 000000	0.24 (8.12)	95 (3.74)	84	245	Standard 11,42	Light 14,85	Basic 18,27	Basic+ 21,70	Exclusive 25,12
Zuckerdose Unterteil 0.25l*	0006 54 4926 12 000000	0.24 (8.12)	95 (3.74)	62	200	6,71	8,72	10,74	12,75	14,76
Zuckerdose Deckel*	0006 54 4927 12 000000		75 (2.95)	26	45	4,71	6,12	7,54	8,95	10,36

*
Auslaufartikel zum 31.12.2026
Discontinued article as of 31/12/2026

BONN/BISTRO

Teller flach rund Fahne, Plate flat round with rim		Untertasse rund, Saucer round	
16 cm 6 54 0016 1	116 mm 160 mm	19 cm 6 54 0119 1	40 mm 113 mm
19 cm 6 54 0019 1	137 mm 189 mm	Teller tief rund Fahne, Plate deep round with rim	14 cm 6 54 6920 1
20 cm 6 54 0020 1	147 mm 202 mm	23 cm 6 54 0123 1	50 mm 141 mm
23 cm 6 54 0023 1	170 mm 231 mm	Platte oval, Platter oval	15 cm 6 54 6925 1
24 cm 6 54 0024 1	180 mm 241 mm	23x16 cm 6 54 2223 1	54 mm 151 mm
25 cm 6 54 0025 1	190 mm 258 mm	26x18 cm 6 54 2226 1	Kombi-Untertasse rund, Combi saucer roundW
27 cm 6 54 0027 1	173 mm 272 mm	29x20 cm 6 54 2229 1	16 cm 6 54 6945 1
30 cm 6 54 0030 1	225 mm 302 mm	32x23 cm 6 54 2232 1	57 mm 156 mm
		37x27 cm 6 54 2237 1	