



MAÎTRE

Teller flach rund Fahne
Plate flat round with rim
Assiette plate ronde avec aile
Plato llano redondo con ala

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Teller flach rund Fahne 17cm	0006 70 0017 12 000000		172 (6.77)	17	255	6,78	8,81	10,85	12,88	14,92
Teller flach rund Fahne 20cm	0006 70 0020 12 000000		200 (7.87)	21	357	7,98	10,37	12,77	15,16	17,56
Teller flach rund Fahne 25cm	0006 70 0025 12 000000		245 (9.65)	22	640	11,94	15,52	19,10	22,69	26,27
Teller flach rund Fahne 28cm	0006 70 0028 12 000000		276 (10.87)	26	845	15,52	20,18	24,83	29,49	34,14
Teller flach rund Fahne 32cm	0006 70 0032 12 000000		314 (12.36)	26	1120	20,30	26,39	32,48	38,57	44,66

Teller flach rund breite Fahne
Plate flat round wide rim
Assiette plate ronde large à bord
Plato llano redondo ancho con ala

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Teller flach rund breite Fahne 16cm	0006 70 0616 12 000000		161 (6.34)	16	220	4,78	6,21	7,65	9,08	10,52
Teller flach rund breite Fahne 21cm	0006 70 0621 12 000000		211 (8.31)	20	405	8,78	11,41	14,05	16,68	19,32
Teller flach rund breite Fahne 24cm	0006 70 0624 12 000000		241 (9.49)	22	560	11,34	14,74	18,14	21,55	24,95
Teller flach rund breite Fahne 26cm	0006 70 0626 12 000000		262 (10.31)	22	620	13,13	17,07	21,01	24,95	28,89
Teller flach rund breite Fahne 28cm	0006 70 0628 12 000000		282 (11.1)	23	760	15,52	20,18	24,83	29,49	34,14
Teller flach rund breite Fahne 32cm	0006 70 0632 12 000000		319 (12.56)	25	1070	20,30	26,39	32,48	38,57	44,66

Teller halbtief rund Fahne
Plate half-deep round with rim
Assiette mi-creuse ronde à bord
Plato semihondo redondo con ala

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Teller halbtief rund Fahne 20cm	0006 70 0220 12 000000	0.23 (7.78)	200 (7.87)	26	360	8,38	10,89	13,41	15,92	18,44

Teller tief rund Fahne
Plate deep round with rim
Assiette creuse ronde avec aile
Plato hondo redondo con ala

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Teller tief rund Fahne 23cm	0006 70 0123 12 000000	0.33 (11.16)	232 (9.13)	31	540	11,34	14,74	18,14	21,55	24,95

Teller tief rund breite Fahne
Plate deep round wide rim
Assiette creuse ronde aile large
Plato hondo redondo ancho con ala

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Teller tief rund breite Fahne 20cm	0006 70 0720 12 000000	0.19 (6.42)	200 (7.87)	35	385	8,38	10,89	13,41	15,92	18,44
Teller tief rund breite Fahne 25cm	0006 70 0725 12 000000	0.38 (12.85)	252 (9.92)	44	700	12,54	16,30	20,06	23,83	27,59
Teller tief rund breite Fahne 28cm	0006 70 0728 12 000000	0.47 (15.89)	284 (11.18)	45	845	16,12	20,96	25,79	30,63	35,46

MAÎTRE

Teller tief rund breite Fahne
Plate deep round wide rim
Assiette creuse ronde aile large
Plato hondo redondo ancho con ala

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Teller tief rund breite Fahne 28cm	0006 70 1928 12 000000	0.30 (10.14)	277 (10.91)	49	825	16,12	20,96	25,79	30,63	35,46

Platte oval Fahne
Platter oval with rim
plat ovale avec aile
Fuente ovalada con ala

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Platte oval Fahne 30x13cm	0006 70 2030 12 000000	302 x 134 (11.89 x 5.28)		25	390	22,59	29,37	36,14	42,92	49,70

Platte oval Fahne
Platter oval with rim
plat ovale avec aile
Fuente ovalada con ala

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Platte oval Fahne 33x20cm	0006 70 2033 12 000000	330 x 198 (12.99 x 7.8)		28	670	25,81	33,55	41,30	49,04	56,78
Platte oval Fahne 38x22cm	0006 70 2038 12 000000	384 x 216 (15.12 x 8.5)		35	940	31,19	40,55	49,90	59,26	68,62

Suppenobertasse stapelbar 0.27l
Creamsoup cup stackable
Tasse à soupe empilable
Taza para sopa apilable

Kombi-Untertasse rund 16cm
Combi saucer round
Soucoupe combi ronde
Platillo combinable redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Suppenobertasse stapelbar 0.27l	0006 70 2826 12 000000	0.27 (9.13)	98 (3.86)	56	260	9,03	11,74	14,45	17,16	19,87
Kombi-Untertasse rund 16cm	0006 70 6918 12 000000		160 (6.3)	21	220	4,78	6,21	7,65	9,08	10,52

Obertasse stapelbar 0.09l
Cup stackable
Tasse empilable
Taza apilable

Untertasse rund 13cm
Saucer round
Soucoupe ronde
Platillo redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Obertasse stapelbar 0.09l	0006 70 5209 12 000000	0.09 (3.04)	56 (2.2)	58	105	5,88	7,64	9,41	11,17	12,94
Untertasse rund 13cm	0006 70 6909 12 000000		125 (4.92)	17	120	4,06	5,28	6,50	7,71	8,93



Obertasse stapelbar 0.18l
Cup stackable
Tasse empilable
Taza apilable



Obertasse stapelbar 0.22l
Cup stackable
Tasse empilable
Taza apilable



Obertasse 0.25l
Cup
Tasse
Taza



Kombi-Untertasse rund 16cm
Combi saucer round
Soucoupe combi ronde
Platillo combinable redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
Obertasse stapelbar 0.18l	0006 70 5218 12 000000	0.19 (6.42)	72 (2.83)	72	190	Standard	Light	Basic	Basic+	Exclusive
Obertasse stapelbar 0.22l	0006 70 5222 12 000000	0.22 (7.44)	71 (2.8)	86	220	7,17	9,32	11,47	13,62	15,77
Obertasse 0.25l	0006 70 5275 12 000000	0.25 (8.45)	105 (4.13)	61	200	7,74	10,06	12,38	14,71	17,03
						8,17	10,62	13,07	15,52	17,97
Kombi-Untertasse rund 16cm	0006 70 6918 12 000000		160 (6.3)	21	220	4,78	6,21	7,65	9,08	10,52



Obertasse 0.35l
Cup
Tasse
Taza



Becher stapelbar 0.30l
Mug stackable
Gobelet empilable
Vaso apilable



Untertasse rund 17cm
Saucer round
Soucoupe ronde
Platillo redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
Obertasse 0.35l	0006 70 5285 12 000000	0.35 (11.83)	117 (4.61)	66	270	Standard	Light	Basic	Basic+	Exclusive
Becher stapelbar 0.30l	0006 70 5228 12 000000	0.30 (10.14)	81 (3.19)	81	210	9,61	12,49	15,38	18,26	21,14
Untertasse rund 17cm	0006 70 6935 12 000000		174 (6.85)	20	280	8,60	11,18	13,76	16,34	18,92
						5,26	6,84	8,42	9,99	11,57



Bowl rund stapelbar 10cm/0.26l

Bowl round stackable
Bol rond empilable
Tazón redondo apilable



Kombi-Untertasse rund 16cm

Combi saucer round
Soucoupe combi ronde
Platillo combinable redondo

#										
Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm						Euro
Bowl rund stapelbar 10cm/0.26l	0006 70 6626 12 000000	0.27 (9.13)	99 (3.9)	55	230	7,60	9,88	12,16	14,44	16,72
Kombi-Untertasse rund 16cm	0006 70 6918 12 000000		160 (6.3)	21	220	4,78	6,21	7,65	9,08	10,52



Schale rund 12cm/0.36l

Bowl round
Bol rond
Bowl redondo

#										
Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm						Euro
						Standard	Light	Basic	Basic+	Exclusive
Schale rund 12cm/0.36l	0006 70 5712 12 000000	0.36 (12.17)	121 (4.76)	55	215	8,89	11,56	14,22	16,89	19,56

	Schüssel rund 15cm/0.65l Bowl round Saladier rond Bol redondo		Schüssel rund 17cm/0.85l Bowl round Saladier rond Bol redondo		Schüssel rund 20cm/1.24l Bowl round Saladier rond Bol redondo					
	# Art.-Nr. (Art.No.)	 Ltr. (fl.oz)	 mm (inch)	 mm	 Gramm	 Euro				
Schüssel rund 15cm/0.65l	0006 70 5715 12 000000	0.65 (21.98)	149 (5.87)	64	390	Standard	Light	Basic	Basic+	Exclusive
Schüssel rund 17cm/0.85l	0006 70 5717 12 000000	0.85 (28.74)	172 (6.77)	65	500	13,19	17,15	21,10	25,06	29,02
Schüssel rund 20cm/1.24l	0006 70 5720 12 000000	1.24 (41.93)	203 (7.99)	65	700	16,06	20,88	25,70	30,51	35,33
						21,65	28,15	34,64	41,14	47,63

	Kaffeekanne Komplett 0.30l Coffee pot Cafetière Cafetera		Kaffeekanne Unterteil 0.30l Coffee pot Cafetière Cafetera		Kaffeekanne Deckel Coffee pot Cafetière Cafetera					
	 # Art.-Nr. (Art.No.)	 Ltr. (fl.oz)	 mm (inch)	 mm	 Gramm	 Euro				
Kaffeekanne Komplett 0.30l	0006 70 4130 13 000000	0.30 (10.14)	150 (5.91)	124	370	Standard	Light	Basic	Basic+	Exclusive
Kaffeekanne Unterteil 0.30l	0006 70 4131 12 000000	0.30 (10.14)	150 (5.91)	103	300	15,92	20,70	25,47	30,25	35,02
Kaffeekanne Deckel	0006 70 4132 12 000000		68 (2.68)	34	70	5,57	7,24	8,91	10,58	12,25

	Teekanne Komplett 0.35l Teapot Théière Tetera		Teekanne Unterteil 0.35l Teapot Théière Tetera		Teekanne Deckel Teapot Théière Tetera					
	# Art.-Nr. (Art.No.)	 Ltr. (fl.oz)	 mm (inch)	 mm	 Gramm	 Euro				
Teekanne Komplett 0.35l	0006 70 4338 13 000000	0.35 (11.83)	168 (6.61)	110	460	Standard	Light	Basic	Basic+	Exclusive
Teekanne Unterteil 0.35l	0006 70 4339 12 000000	0.35 (11.83)	168 (6.61)	84	360	17,51	22,76	28,02	33,27	38,52
Teekanne Deckel	0006 70 4340 12 000000		88 (3.46)	37	100	6,21	8,07	9,94	11,80	13,66



Gießer 0.15l

Creamer
Crémier
Jarra

#										
Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm					Euro	
					Standard	Light	Basic	Basic+	Exclusive	
Gießer 0.15l	0006 70 4715 12 000000	0.15 (5.07)	105 (4.13)	73	170	11,14	14,48	17,82	21,17	24,51

	Zuckerdose Komplett 0.25l Sugar bowl Sucrier Azucarero		Zuckerdose Unterteil 0.25l Sugar bowl Sucrier Azucarero		Zuckerdose Deckel Sugar bowl Sucrier Azucarero					
	# Art.-Nr. (Art.No.)	 Ltr. (fl.oz)	 mm (inch)	 mm	 Gramm	 Euro				
Zuckerdose Komplett 0.25l*	0006 70 4925 13 000000	0.25 (8.45)	105 (4.13)	90	305	Standard	Light	Basic	Basic+	Exclusive
Zuckerdose Unterteil 0.25l	0006 70 4926 12 000000	0.25 (8.45)	105 (4.13)	62	195	7,46	9,70	11,94	14,17	16,41
Zuckerdose Deckel*	0006 70 4927 12 000000		108 (4.25)	35	110	5,27	6,85	8,43	10,01	11,59

*
Auslaufartikel zum 31.12.2026
Discontinued article as of 31/12/2026

MAÎTRE

Teller flach rund Fahne, Plate flat round with rim	Teller flach rund breite Fahne, Plate flat round wide rim	Teller halbtief rund Fahne, Plate half-deep round with rim
17 cm 6 70 0017 1	16 cm 6 70 0616 1	20 cm 6 70 0220 1
 124 mm 172 mm	 91 mm 161 mm	 153 mm 200 mm
20 cm 6 70 0020 1	21 cm 6 70 0621 1	Teller tief rund Fahne, Plate deepround with rim
 145 mm 200 mm	 141 mm 211 mm	23 cm 6 70 0123 1
25 cm 6 70 0025 1	24 cm 6 70 0624 1	 174 mm 232 mm
 185 mm 245 mm	 153 mm 241 mm	
28 cm 6 70 0028 1	26 cm 6 70 0626 1	
 208 mm 276 mm	 180 mm 262 mm	
32 cm 6 70 0032 1	28 cm 6 70 0628 1	
 215 mm 314 mm	 195 mm 282 mm	
	32 cm 6 70 0632 1	
	 203 mm 319 mm	

MAÎTRE

Teller tief rund breite Fahne, Plate deep round with wide rim	Platte oval Fahne, Platter oval with rim	Kombi-Untertasse rund, Combi saucer round
20 cm 6 70 0720 1	30x13 cm 6 70 2030 1	16 cm 6 70 6918 1
 129 mm 200 mm	 200x91 mm 302 x 134 mm	 62 mm 160 mm
25 cm 6 70 0725 1	33x20 cm 6 70 2033 1	Untertasse rund, Saucer round
 160 mm 252 mm	 248 x 140 mm 330 x 198 mm	13 cm 6 70 6909 1
28 cm 6 70 0728 1	38x22 cm 6 70 2038 1	 46 mm 125 mm
 180 mm 284 mm	 287 x 158 mm 384 x 216 mm	17 cm 6 70 6935 1
 143 mm 277 mm		 70 mm 174 mm
Teller tief rund breite Fahne, Plate deep round with wide rim		
28 cm 6 70 1928 1		