



MARIE CHRISTINE

Teller flach rund Fahne
Plate flat round with rim
Assiette plate ronde avec aile
Plato llano redondo con ala

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Teller flach rund Fahne 15cm	0006 45 0015 12 000000		155 (6.1)	22	180	5,00	6,50	8,00	9,50	11,00
Teller flach rund Fahne 17cm	0006 45 0017 12 000000		172 (6.77)	24	225	7,46	9,70	11,94	14,17	16,41
Teller flach rund Fahne 19cm	0006 45 0019 12 000000		193 (7.6)	26	270	8,34	10,84	13,34	15,85	18,35
Teller flach rund Fahne 21cm	0006 45 0021 12 000000		218 (8.58)	31	380	9,66	12,56	15,46	18,35	21,25
Teller flach rund Fahne 25cm	0006 45 0025 12 000000		250 (9.84)	29	585	13,13	17,07	21,01	24,95	28,89
Teller flach rund Fahne 28cm	0006 45 0028 12 000000		276 (10.87)	31	780	17,07	22,19	27,31	32,43	37,55
Teller flach rund Fahne 31cm	0006 45 0030 12 000000		310 (12.2)	28	1000	19,70	25,61	31,52	37,43	43,34

Teller flach rund coup
Plate flat round coupe
Assiette plate ronde coupe
Plato llano redondo coupe

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Teller flach rund coup 16cm	0006 45 1216 12 000000		158 (6.22)	20	175	5,26	6,84	8,42	9,99	11,57
Teller flach rund coup 20cm	0006 45 1220 12 000000		200 (7.87)	24	320	8,78	11,41	14,05	16,68	19,32
Teller flach rund coup 27cm	0006 45 1227 12 000000		272 (10.71)	28	740	15,76	20,49	25,22	29,94	34,67

Teller tief rund Fahne
Plate deep round with rim
Assiette creuse ronde avec aile
Plato hondo redondo con ala

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Teller tief rund Fahne 23cm	0006 45 0123 12 000000	0.39 (13.19)	234 (9.21)	48	500	12,48	16,22	19,97	23,71	27,46
Teller tief rund Fahne 28cm	0006 45 0128 12 000000	0.63 (21.30)	279 (10.98)	52	775	17,73	23,05	28,37	33,69	39,01

Platte oval Fahne
Platter oval with rim
plat ovale avec aile
Fuente ovalada con ala

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Platte oval Fahne 25x17cm	0006 45 2025 12 000000		242 x 164 (9.53 x 6.46)	39	450	18,93	24,61	30,29	35,97	41,65
Platte oval Fahne 30x19cm	0006 45 2030 12 000000		309 x 195 (12.17 x 7.68)	44	840	24,84	32,29	39,74	47,20	54,65
Platte oval Fahne 35x23cm	0006 45 2035 12 000000		355 x 238 (13.98 x 9.37)	46	1060	30,76	39,99	49,22	58,44	67,67

Suppenobertasse stapelbar 0.28l
Creamsoup cup stackable
Tasse à soupe empilable
Taza para sopa apilable

Untertasse rund 15cm
Saucer round
Soucoupe ronde
Platillo redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Suppenobertasse stapelbar 0.28l	0006 45 2828 12 000000	0.28 (9.47)	109 (4.29)	56	300	10,25	13,33	16,40	19,48	22,55
Untertasse rund 15cm	0006 45 6918 12 000000		153 (6.02)	22	211	5,00	6,50	8,00	9,50	11,00

MARIE CHRISTINE

Obertasse 0.09l
Cup
Tasse
Taza

Untertasse rund 11cm
Saucer round
Soucoupe ronde
Platillo redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Obertasse 0.09l	0006 45 5259 12 000000	0.09 (3.04)	69 (2.72)	50	95	6,47	8,41	10,35	12,29	14,23
Untertasse rund 11cm	0006 45 6909 12 000000		114 (4.49)	25	112	3,94	5,12	6,30	7,49	8,67

Obertasse 0.19l
Cup
Tasse
Taza

Obertasse 0.22l
Cup
Tasse
Taza

Untertasse rund 14cm
Saucer round
Soucoupe ronde
Platillo redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Obertasse 0.19l	0006 45 5269 12 000000	0.20 (6.76)	87 (3.43)	67	195	8,04	10,45	12,86	15,28	17,69
Obertasse 0.22l	0006 45 5272 12 000000	0.22 (7.44)	92 (3.62)	70	210	8,52	11,08	13,63	16,19	18,74
Untertasse rund 14cm	0006 45 6919 12 000000		143 (5.63)	28	155	4,73	6,15	7,57	8,99	10,41

Obertasse 0.34l
Cup
Tasse
Taza

Untertasse rund 15cm
Saucer round
Soucoupe ronde
Platillo redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Obertasse 0.34l	0006 45 5285 12 000000	0.35 (11.83)	104 (4.09)	80	290	10,41	13,53	16,66	19,78	22,90
Untertasse rund 15cm	0006 45 6935 12 000000		153 (6.02)	38	220	5,00	6,50	8,00	9,50	11,00

Obertasse stapelbar 0.18l
Cup stackable
Tasse empilable
Taza apilable

Untertasse rund 15cm
Saucer round
Soucoupe ronde
Platillo redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Obertasse stapelbar 0.18l	0006 45 5218 12 000000	0.20 (6.76)	86 (3.39)	55	198	7,89	10,26	12,62	14,99	17,36
Untertasse rund 15cm	0006 45 6918 12 000000		153 (6.02)	22	211	5,00	6,50	8,00	9,50	11,00

Becher 0.36l
Mug
Gobelet
Vaso

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Becher 0.36l*	0006 45 5635 12 000000	0.36 (12.17)	93 (3.66)	86	330	9,61	12,49	15,38	18,26	21,14

*
Auslaufartikel zum 31.12.2026
Discontinued article as of 31/12/2026

MARIE CHRISTINE

Schälchen rund
Small dish round
Petit bol rond
Recipiente redondo

Schale rund
Bowl round
Bol rond
Bowl redondo

Schüssel rund
Bowl round
Saladler rond
Bol redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Schälchen rund 10cm	0006 45 5760 12 000000		104 (4.09)	17	87	4,22	5,49	6,75	8,02	9,28
Schale rund 13cm/0.20l	0006 45 3063 12 000000	0.20 (6.76)	136 (5.35)	33	165	7,41	9,63	11,86	14,08	16,30
Schüssel rund 17cm/0.48l	0006 45 3167 12 000000	0.48 (16.23)	171 (6.73)	47	300	11,83	15,38	18,93	22,48	26,03
Schüssel rund 21cm/0.90l	0006 45 3171 12 000000	0.90 (30.43)	212 (8.35)	57	510	18,46	24,00	29,54	35,07	40,61

**Kaffee- und Teekanne Relief Kom-
plett 0.30l**
Coffee and teapot
Cafetière et théière relief
Cafetera y tetera relieve

**Kaffee- und Teekanne Relief Unter-
teil 0.30l**
Coffee and teapot
Cafetière et théière relief
Cafetera y tetera relieve

Kaffee- und Teekanne Relief Deckel
Coffee and teapot
Cafetière et théière relief
Cafetera y tetera relieve

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Kaffee- und Teekanne Relief Komplett 0.30l*	0006 45 4130 13 000000	0.35 (11.83)	89 (3.5)	155	350	23,64	30,73	37,82	44,92	52,01
Kaffee- und Teekanne Relief Unterteil 0.30l*	0006 45 4131 12 000000	0.35 (11.83)	88 (3.46)	118	270	17,51	22,76	28,02	33,27	38,52
Kaffee- und Teekanne Relief Deckel*	0006 45 4132 12 000000		68 (2.68)	52	80	6,13	7,97	9,81	11,65	13,49

Teekanne Relief Komplett 0.40l
Teapot embossed
Théière relief
Tetera relieve

Teekanne Relief Unterteil 0.40l
Teapot embossed
Théière relief
Tetera relieve

Kaffee- und Teekanne Relief Deckel
Coffee and teapot
Cafetière et théière relief
Cafetera y tetera relieve

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Teekanne Relief Komplett 0.40l*	0006 45 4340 13 000000	0.40 (13.53)	102 (4.02)	133	380	27,14	35,28	43,42	51,57	59,71
Teekanne Relief Unterteil 0.40l*	0006 45 4341 12 000000	0.40 (13.53)	102 (4.02)	94	310	21,01	27,31	33,62	39,92	46,22
Kaffee- und Teekanne Relief Deckel*	0006 45 4132 12 000000		68 (2.68)	52	80	6,13	7,97	9,81	11,65	13,49

Gießer 0.15l
Creamer
Crémier
Jarra

Sauciere 0.12l
Sauce boat
Saucière
Salsera

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Gießer 0.15l	0006 45 4715 12 000000	0.15 (5.07)	73 (2.87)	101	150	12,26	15,94	19,62	23,29	26,97
Sauciere 0.12l*	0006 45 3815 12 000000	0.14 (4.73)	167 x 72 (6.57 x 2.83)	89	220	11,21	14,57	17,94	21,30	24,66

Zuckerdose Relief Komplett 0.25l
Sugar bowl embossed
Sucrier relief
Azucarero relieve

Zuckerdose Relief Unterteil 0.25l
Sugar bowl embossed
Sucrier relief
Azucarero relieve

Zuckerdose Relief Deckel
Sugar bowl embossed
Sucrier relief
Azucarero relieve


	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Zuckerdose Relief Komplett 0.25l*	0006 45 4925 13 000000	0.25 (8.45)	94 (3.7)	110	290	14,94	19,42	23,90	28,39	32,87
Zuckerdose Relief Unterteil 0.25l*	0006 45 4926 12 000000	0.25 (8.45)	88 (3.46)	61	190	8,20	10,66	13,12	15,58	18,04
Zuckerdose Relief Deckel*	0006 45 4927 12 000000		94 (3.7)	49	100	6,74	8,76	10,78	12,81	14,83

*
Auslaufartikel zum 31.12.2026
Discontinued article as of 31/12/2026


MARIE CHRISTINE

Teller flach rund Fahne,
Plate flat round with rimt

15 cm
6 45 0015 1



17 cm
6 45 0017 1



19 cm
6 45 0019 1



21 cm
6 45 0021 1



25 cm
6 45 0025 1



28 cm
6 45 0028 1



30 cm
6 45 0030 1




Teller tief rund Fahne,
Plate deep round with rim

23 cm
6 45 0123 1



28 cm
6 45 0128 1



Platte oval Fahne,
Platter oval with rim

25x17 cm
6 45 2025 1



30x19 cm
6 45 2030 1



35x23 cm
6 45 2035 1



Untertasse rund,
Saucer round

11 cm
6 45 6909 1



14 cm
6 45 6919 1



15 cm
6 45 6935 1



Untertasse rund,
Saucer round

15 cm
6 45 6918 1

