



ADDITIONS

Pots & Pourers

The art of pouring

Celebrating tea, presenting coffee with style, and showcasing sauces or jus with elegance: POTS & POURERS made from selected materials such as stoneware, cast iron, or glass transform the moment into one of pure indulgence. Whether bold and archaic or delicate and transparent, these ADDITIONS blend in harmoniously. Pouring becomes a special gesture of hospitality.



Tee zelebrieren, Kaffee inszenieren und Saucen oder Jus elegant präsentieren: POTS & POURERS aus ausgewählten Materialien wie Steinzeug, Gusseisen oder Glas machen den Moment zu einem Genussritual. Ob markant und archaisch oder fein und transparent, diese ADDITIONS fügen sich harmonisch ein. So wird Eingießen zu einem besonderen Moment der Gastfreundschaft.



STONEWARE

PLATFORMS

SPOTLIGHTS

ADDITIONS

POTS & POURERS | GLASS



TEEKANNE
TEAPOT
GROSS/LARGE

0007 51 4300 91 000000

17cm x 10cm / 6.69" x 3.94"

0.40l / 13.53oz

140 g

10cm / 3.94"

1

10,29 €



TEEKANNE
TEAPOT
KLEIN/SMALL

0007 51 4301 91 000000

10.5cm x 6cm / 4.13" x 2.36"

0.08l / 2.71oz

40 g

6.5cm / 2.56"

1

7,48 €



SLOW COFFEE MAKER
SLOW COFFEE MAKER
SILBER/SILVER 0.60L

0007 51 9000 91 000000

13.5cm x 12cm / 5.31" x 4.72"

0.60l / 20.29oz

380 g

16cm / 6.3"

1

41,84 €



SLOW COFFEE MAKER
SLOW COFFEE MAKER
GOLD 0.60L

0007 51 9001 91 000000

13.5cm x 12cm / 5.31" x 4.72"

0.60l / 20.29oz

380 g

16cm / 6.3"

1

41,84 €



SLOW COFFEE MAKER
SLOW COFFEE MAKER
0.60L

0007 51 9002 91 000000

Ø13.5cm / Ø5.31"

0.60l / 20.29oz

256 g

16cm / 6.3"

1

21,68 €

POTS & POURERS | STONEWARE



GIESSER OHNE HENKEL
CREAMER WITHOUT HANDLE
0.20L

0007 01 4600 91 004262

Ø8cm / Ø3.15"

0.22l / 7.44oz

175 g

8.9cm / 3.5"

6

6,65 €

POTS & POURERS | CAST IRON



TEEKANNE MIT SIEB
TEAPOT WITH STRAINER
BRONZE 0.30L

0007 21 4304 91 000000

12cm x 9cm / 4.72" x 3.54"

0.30l / 10.14oz

700 g

8cm / 3.15"

1

19,22 €



TEEKANNE MIT SIEB
TEAPOT WITH STRAINER
BLAU/BLUE 0.50L

0007 21 4306 91 000000

15cm x 12cm / 5.91" x 4.72"

0.50l / 16.91oz

1100 g

11cm / 4.33"

1

23,38 €



TEEKANNE MIT SIEB
TEAPOT WITH STRAINER
SALBEI/SAGE 0.40L

0007 21 4305 91 000000

15cm x 14cm / 5.91" x 5.51"

0.40l / 13.53oz

1000 g

8cm / 3.15"

1

21,30 €



TEEKANNE MIT SIEB
TEAPOT WITH STRAINER
BRAUN/BROWN 0.45L

0007 21 4307 91 000000

15cm x 13cm / 5.91" x 5.12"

0.45l / 15.22oz

1100 g

8cm / 3.15"

1

22,34 €



TEEKANNE MIT SIEB
TEAPOT WITH STRAINER
SCHWARZ/BLACK 0.50L

0007 21 4303 91 000000

15cm x 13cm / 5.91" x 5.12"

0.50l / 16.91oz

950 g

9cm / 3.54"

1

23,38 €



TEEKANNE MIT SIEB
TEAPOT WITH STRAINER
1.10L

0007 21 4302 91 000000

22cm x 19.5cm / 8.66" x 7.68"

1.15l / 38.89oz

2234 g

8cm / 3.15"

1

67,65 €

POTS & POURERS | WOOD



STÖVCHEN
WARMER
EICHE/OAK 14X14CM

0007 41 7900 91 000000

14cm x 14cm / 5.51" x 5.51"

-

420 g

5.5cm / 2.17"

1

31,11 €



STÖVCHEN
WARMER
NUSSBAUM/WALNUT 14X14CM

0007 42 7900 91 000000

14cm x 14cm / 5.51" x 5.51"

-

360 g

5.5cm / 2.17"

1

35,18 €

