



DELIGHT

Teller flach rund Fahne
Plate flat round with rim
Assiette plate ronde avec aile
Plato llano redondo con ala

#	Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Standard	Light	Basic	Basic+	Exclusive	Euro
Teller flach rund Fahne 16cm	0009 82 0016 62 000000		160 (6.3)	19	195	5,74	7,46	9,18	10,91	12,63	
Teller flach rund Fahne 21cm	0009 82 0021 62 000000		215 (8.46)	18	335	10,53	13,69	16,85	20,01	23,17	
Teller flach rund Fahne 23cm	0009 82 0023 62 000000		233 (9.17)	21	480	12,90	16,77	20,64	24,51	28,38	
Teller flach rund Fahne 26cm	0009 82 0026 62 000000		260 (10.24)	23	620	15,76	20,49	25,22	29,94	34,67	
Teller flach rund Fahne 28cm	0009 82 0028 62 000000		281 (11.06)	24	710	18,63	24,22	29,81	35,40	40,99	
Teller flach rund Fahne 31cm	0009 82 0031 62 000000		313 (12.32)	23	925	22,92	29,80	36,67	43,55	50,42	

Teller flach rund coup
Plate flat round coupe
Assiette plate ronde coupe
Plato llano redondo coupe

#	Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Standard	Light	Basic	Basic+	Exclusive	Euro
Teller flach rund coup 12cm	0009 82 1212 62 000000		121 (4.76)	17	115	4,59	5,97	7,34	8,72	10,10	
Teller flach rund coup 16cm	0009 82 1216 62 000000		160 (6.3)	18	210	5,74	7,46	9,18	10,91	12,63	
Teller flach rund coup 21cm	0009 82 1221 62 000000		209 (8.23)	20	383	10,53	13,69	16,85	20,01	23,17	
Teller flach rund coup 24cm	0009 82 1224 62 000000		240 (9.45)	23	540	13,61	17,69	21,78	25,86	29,94	
Teller flach rund coup 27cm	0009 82 1227 62 000000		270 (10.63)	24	715	17,19	22,35	27,50	32,66	37,82	
Teller flach rund coup 29cm	0009 82 1229 62 000000		291 (11.46)	26	860	20,06	26,08	32,10	38,11	44,13	
Teller flach rund coup 31cm	0009 82 1231 62 000000		308 (12.13)	25	992	22,92	29,80	36,67	43,55	50,42	

Teller tief rund Fahne
Plate deep round with rim
Assiette creuse ronde avec aile
Plato hondo redondo con ala

#	Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Standard	Light	Basic	Basic+	Exclusive	Euro
Teller tief rund Fahne 20cm	0009 82 0120 62 000000	0.16 (5.41)	200 (7.87)	38	340	10,05	13,07	16,08	19,10	22,11	
Teller tief rund Fahne 24cm	0009 82 0124 62 000000	0.25 (8.45)	240 (9.45)	46	500	14,33	18,63	22,93	27,23	31,53	
Teller tief rund Fahne 28cm	0009 82 0128 62 000000	0.43 (14.54)	279 (10.98)	54	730	19,34	25,14	30,94	36,75	42,55	

Teller tief rund coup
Plate deep round coupe
Assiette creuse ronde coupe
Plato hondo redondo coupe

#	Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Standard	Light	Basic	Basic+	Exclusive	Euro
Teller tief rund coup 23cm	0009 82 1323 62 000000	0.85 (28.74)	230 (9.06)	37	530	13,61	17,69	21,78	25,86	29,94	
Teller tief rund coup 27cm	0009 82 1327 62 000000	1.25 (42.27)	271 (10.67)	43	760	17,91	23,28	28,66	34,03	39,40	
Teller tief rund coup 31cm	0009 82 1331 62 000000	1.80 (60.87)	310 (12.2)	43	1055	23,64	30,73	37,82	44,92	52,01	

DELIGHT

Platte oval Fahne
Platter oval with rim
plat ovale avec aile
Fuente ovalada con ala

#	Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Standard	Light	Basic	Basic+	Exclusive	Euro
Platte oval Fahne 24x15cm	0009 82 2024 62 000000		240 x 151 (9.45 x 5.94)	22	330	19,62	25,51	31,39	37,28	43,16	
Platte oval Fahne 34x23cm	0009 82 2034 62 000000		340 x 233 (13.39 x 9.17)	24	690	32,27	41,95	51,63	61,31	70,99	
Platte oval Fahne 38x27cm	0009 82 2038 62 000000		381 x 274 (15 x 10.79)	27	960	37,43	48,66	59,89	71,12	82,35	

Platte oval coup 45x20cm

Platter oval coupe
Plat oval coupe
Fuente ovalada coupe

#	Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Standard	Light	Basic	Basic+	Exclusive	Euro
Platte oval coup 45x20cm	0009 82 2245 62 000000		451 x 197 (17.76 x 7.76)	30	1100	46,46	60,40	74,34	88,27	102,21	

Platte Special 19x9cm

Platter special
Plat spécial
Fuente especial

Platte Special 19x9cm

Platte Special 28x9cm

#	Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Standard	Light	Basic	Basic+	Exclusive	Euro
Platte Special 19x9cm	0009 82 2619 62 000000		190 x 91 (7.48 x 3.58)	27	160	10,43	13,56	16,69	19,82	22,95	
Platte Special 28x9cm	0009 82 2628 62 000000	0.12 (4.06)	280 x 94 (11.02 x 3.7)	37	290	24,73	32,15	39,57	46,99	54,41	

Suppenobertasse 0.35l

Creamsoup cup
Tasse à soupe
Taza para sopa

Suppenobertasse 0.35l

Suppenobertasse stapelbar 0.35l

#	Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Standard	Light	Basic	Basic+	Exclusive	Euro
Suppenobertasse 0.35l	0009 82 2835 62 000000	0.35 (11.83)	115 (4.53)	61	235	12,39	16,11	19,82	23,54	27,26	
Suppenobertasse stapelbar 0.35l	0009 82 2935 62 000000	0.35 (11.83)	103 (4.06)	63	280	12,39	16,11	19,82	23,54	27,26	
Kombi-Untertasse rund 16cm	0009 82 6919 62 000000		159 (6.26)	18	185						

DELIGHT

Obertasse 0.19l		Obertasse 0.24l		Obertasse 0.28l						
Cup Tasse Taza		Cup Tasse Taza		Cup Tasse Taza						
Obertasse 0.35l		Kombi-Untertasse rund 16cm								
Cup Tasse Taza		Combi saucer round Soucoupe combi ronde Platillo combinable redondo								
# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Standard	Light	Basic	Basic+	Exclusive	
Obertasse 0.19l Obertasse 0.24l Obertasse 0.28l Obertasse 0.35l	0009 82 5269 62 000000 0009 82 5274 62 000000 0009 82 5278 62 000000 0009 82 5285 62 000000	0.19 (6.42) 0.24 (8.12) 0.28 (9.47) 0.35 (11.83)	92 (3.62) 102 (4.02) 107 (4.21) 115 (4.53)	50 51 56 61	145 165 190 230	8,78 9,64 10,32 11,53	11,41 12,53 13,42 14,99	14,05 15,42 16,51 18,45	16,68 18,32 19,61 21,91	19,32 21,21 22,70 25,37
Kombi-Untertasse rund 16cm	0009 82 6919 62 000000		159 (6.26)	18	185	5,74	7,46	9,18	10,91	12,63

Obertasse stapelbar 0.09l		Untertasse rund 13cm			
Cup stackable Tasse empilable Taza apilable		Saucer round Soucoupe ronde Platillo redondo			
#	Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)		
Obertasse stapelbar 0.09l	0009 82 5309 62 000000	0.09 (3.04)	58 (2.28) 54 110		
Untertasse rund 13cm	0009 82 6908 62 000000		132 (5.2) 18 120		
Gramm	Standard	Light	Basic	Basic+	Exclusive
	7,06	9,18	11,30	13,41	15,53
	4,88	6,34	7,81	9,27	10,74

Obertasse stapelbar 0.19l Cup stackable Tasse empilable Taza apilable		Obertasse stapelbar 0.24l Cup stackable Tasse empilable Taza apilable		Kombi-Untertasse rund 16cm Combi saucer round Soucoupe combi ronde Platillo combinable redondo			
# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Standard Light Basic Basic+ Exclusive		
Obertasse stapelbar 0.19l Obertasse stapelbar 0.24l	0009 82 5319 62 000000 0009 82 5324 62 000000	0.19 (6.42) 0.24 (8.12)	71 (2.8) 71 (2.8)	69 85 230	180 9,64 12,53	8,78 11,41 14,05 15,42	19,32 16,68 14,05 18,32
Kombi-Untertasse rund 16cm	0009 82 6919 62 000000	150 (6.26)	18	195	5,74 7,46 9,18 10,91 12,63		

	Becher 0.30l Mug Gobelet Vaso		Kombi-Untertasse rund 16cm Combi saucer round Soucoupe combi ronde Platillo combinable redondo
# Art.-Nr. (Art.No.) Ltr. (fl.oz) mm (inch) mm Gramm Standard Light Basic Basic+ Exclusive Euro			
Becher 0.30l	0009 82 5680 62 000000	0.31 (10.48)	88 (3.46) 91 275 10,67 13,87 17,07 20,27 23,47
Kombi-Untertasse rund 16cm	0009 82 6919 62 000000	159 (6.26)	18 185 5,74 7,46 9,18 10,91 12,63

DELIGHT

Bowl rund 7cm/0.08l		Untertasse rund 13cm	
Bowl round Bol rond Tazón redondo		Saucer round Soucoupe ronde Platillo redondo	


	Bowl rund 9cm/0.19l Bowl round Bol rond Tazón redondo		Bowl rund 12cm/0.35l Bowl round Bol rond Tazón redondo		Kombi-Untertasse rund 16cm Combi saucer round Soucoupe combi ronde Platillo combinable redondo					
#	Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Standard	Light	Basic	Basic+	Exclusive
Bowl rund 9cm/0.19l	0009 82 6669 62 000000	0.19 (6.42)	92 (3.62)	50	140	7,92	10,30	12,67	15,05	17,42
Bowl rund 12cm/0.35l	0009 82 6685 62 000000	0.35 (11.83)	115 (4.53)	61	220	10,67	13,87	17,07	20,27	23,47
Kombi-Untertasse rund 16cm	0009 82 6919 62 000000		159 (6.26)	18	185	5,74	7,46	9,18	10,91	12,63

	Bowl rund stapelbar 7cm/0.19l	Bowl round stackable Bol rond empilable Tazón redondo apilable	 #	Art.-Nr. (Art.No.)	 Ltr. (fl.oz)	 mm (inch)	 mm	 Gramm	 Standard 7,92	 Light 10,30	 Basic 12,67	 Basic+ 15,05	Exclusive 17,42
Bowl rund stapelbar 7cm/0.19l	0009 82 6649 62 000000	0.19 (6.42)				71 (2.8)	69	170					

 Schälchen Special 9x7cm/0.04l	Schälchen Special 9x7cm/0.04l	Small dish special Petit bol spécial Recipiente especial	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Standard 6,19	Light 8,05	Basic 9,90	Basic+ 11,76	Exclusive 13,62
Schälchen Special 9x7cm/0.04l	0009 82 6109 62 000000	0.04 (1.35)	90 x 74 (3.54 x 2.91)	34	79							

Schale rund 13cm/0.31l	Schüssel rund 16cm/0.50l	Schüssel rund 20cm/1.10l								
Bowl round	Bowl round	Bowl round								
Bol rond	Saladier rond	Saladier rond								
Bowl redondo	Bol redondo	Bol redondo								
#										
Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)								
mm	Gramm									
		Standard Light Basic Basic+ Exclusive								
Schale rund 13cm/0.31l	0009 82 3063 62 000000	0.31 (10.48)	132 (5.2)	39	210	9,98	12,97	15,97	18,96	21,96
Schüssel rund 16cm/0.50l	0009 82 3166 62 000000	0.50 (16.91)	160 (6.3)	46	300	13,25	17,23	21,20	25,18	29,15
Schüssel rund 20cm/1.10l	0009 82 3170 62 000000	1.10 (37.20)	200 (7.87)	60	560	21,85	28,41	34,96	41,52	48,07

DELIGHT



Schüssel Special 28x19cm/0.55l

Bowl special
Saladier spécial
Bol especial

#	Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Standard	Light	Basic	Basic+	Exclusive	Euro
Schüssel Special 28x19cm/0.55l	0009 82 6128 62 000000	0.55 (18.60)	279 x 185 (10.98 x 7.28)	57	510	27,08	35,20	43,33	51,45	59,58	



Kaffee- und Teekanne Komplett 0.30l

Coffee and teapot
Cafetièr et théière
Cafetera y tetera



Kaffee- und Teekanne Unterteil 0.30l

Coffee and teapot
Cafetièr et théière
Cafetera y tetera

#	Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Standard	Light	Basic	Basic+	Exclusive	Euro
Kaffee- und Teekanne Komplett 0.30l	0009 82 4130 63 000000	0.30 (10.14)	95 (3.74)	135	360	25,79	33,53	41,26	49,00	56,74	
Kaffee- und Teekanne Unterteil 0.30l	0009 82 4131 62 000000	0.30 (10.14)	95 (3.74)	113	280	19,10	24,83	30,56	36,29	42,02	
Kaffee- und Teekanne Deckel	0009 82 4132 62 000000		73 (2.87)	32	80	6,69	8,70	10,70	12,71	14,72	



Teekanne Komplett 0.40l

Teapot
Théière
Tetera



Teekanne Unterteil 0.40l

Teapot
Théière
Tetera

#	Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Standard	Light	Basic	Basic+	Exclusive	Euro
Teekanne Komplett 0.40l	0009 82 4340 63 000000	0.40 (13.53)	129 (5.08)	115	450	29,61	38,49	47,38	56,26	65,14	
Teekanne Unterteil 0.40l	0009 82 4341 62 000000	0.40 (13.53)	129 (5.08)	93	370	22,92	29,80	36,67	43,55	50,42	
Kaffee- und Teekanne Deckel	0009 82 4132 62 000000		73 (2.87)	32	80	6,69	8,70	10,70	12,71	14,72	



Gießer ohne Henkel 0.05l

Creamer without handle
Crémier sans anse
Jarra sin asa



Gießer 0.15l

Creamer
Crémier
Jarra

#	Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Standard	Light	Basic	Basic+	Exclusive	Euro
Gießer ohne Henkel 0.05l	0009 82 4605 62 000000	0.05 (1.69)	51 (2.01)	54	55	7,64	9,93	12,22	14,52	16,81	
Gießer 0.15l	0009 82 4715 62 000000	0.15 (5.07)	75 (2.95)	88	150	13,37	17,38	21,39	25,40	29,41	

DELIGHT



Sauciere 0.10l

Sauce boat
Saucière
Salsera



Sauciere 0.30l

Sauce boat
Saucière
Salsera



Untertasse rund 13cm


Saucer round
Soucoupe ronde
Platillo redondo



Kombi-Untertasse rund 16cm

Combi saucer round
Soucoupe combi ronde
Platillo combinable redondo

#	Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Standard	Light	Basic	Basic+	Exclusive	Euro
Sauciere 0.10l	0009 82 3810 62 000000	0.10 (3.38)	81 (3.19)	61	125	11,46	14,90	18,34	21,77	25,21	10,74
Sauciere 0.30l	0009 82 3830 62 000000	0.30 (10.14)	110 (4.33)	80	290	19,10	24,83	30,56	36,29	42,02	



Zuckerdose Komplett 0.19l

Sugar bowl
Sucrerie
Azucarero



Bowl rund 9cm/0.19l

Bowl round
Bol rond
Tazón redondo



Zuckerdose Deckel


Sugar bowl
Sucrerie
Azucarero

#	Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Standard	Light	Basic	Basic+	Exclusive	Euro
Zuckerdose Komplett 0.19l	0009 82 4919 63 000000	0.19 (6.42)	96 (3.78)	70	215	15,28	19,86	24,45	29,03	33,62	
Bowl rund 9cm/0.19l	0009 82 6669 62 000000	0.19 (6.42)	92 (3.62)	50	140	7,92	10,30	12,67	15,05	17,42	
Zuckerdose Deckel	0009 82 4920 62 000000		96 (3.78)	25	75	7,36	9,57	11,78	13,98	16,19	

DELIGHT

Teller flach rund Fahne, Plate flat round with rim

16 cm
9 82 0016 6



87 mm
↔
160 mm

21 cm
9 82 0021 6



141 mm
↔
215 mm

23 cm
9 82 0023 6



154 mm
↔
233 mm

26 cm
9 82 0026 6



174 mm
↔
260 mm

28 cm
9 82 0028 6



186 mm
↔
281 mm

31 cm
9 82 0031 6



194 mm
↔
313 mm


Teller flach rund coup, Plate flat round coupe

12 cm
9 82 1212 6



120 mm

16 cm
9 82 1216 6



160 mm

21 cm
9 82 1221 6




211 mm

24 cm
9 82 1224 6



240 mm

27 cm
9 82 1227 6



270 mm

Teller tief rund Fahne, Plate deep round with rim

20 cm
9 82 0120 6




120 mm

24 cm
9 82 0124 6



140 mm

28 cm
9 82 0128 6



159 mm

279 mm

Platte oval Fahne, Platter oval with rim

24x15 cm
9 82 2024 6



164 x 89 mm

↔
240 x 151 mm

34x23 cm
9 82 2034 6



241 x 152 mm

↔
340 x 233 mm

Untertasse rund, Saucer round

13 cm
9 82 6908 6



38 mm

↔
132 mm

Kombi-Untertasse rund, Combi Saucer round

16 cm
9 82 6919 6



50 mm

↔
159 mm