



FORM 98



Teller flach rund Fahne

Plate flat round with rim
Assiette plate ronde avec aile
Plato llano redondo con ala

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Teller flach rund Fahne 15cm	0009 01 0615 12 000000		155 (6.1)	20	200	4,09	5,32	6,54	7,77	9,00
Teller flach rund Fahne 17cm	0009 01 0617 12 000000		179 (7.05)	20	255	6,10	7,93	9,76	11,59	13,42
Teller flach rund Fahne 19cm	0009 01 0619 12 000000		194 (7.64)	23	350	6,82	8,87	10,91	12,96	15,00
Teller flach rund Fahne 23cm	0009 01 0623 12 000000		236 (9.29)	28	565	9,67	12,57	15,47	18,37	21,27
Teller flach rund Fahne 26cm	0009 01 0626 12 000000		255 (10.04)	26	745	11,82	15,37	18,91	22,46	26,00



Teller flach rund Fahne

Plate flat round with rim
Assiette plate ronde avec aile
Plato llano redondo con ala

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Teller flach rund Fahne 15cm	0009 01 0015 12 000000		150 (5.91)	16	175	4,09	5,32	6,54	7,77	9,00
Teller flach rund Fahne 17cm	0009 01 0017 12 000000		173 (6.81)	17	260	6,10	7,93	9,76	11,59	13,42
Teller flach rund Fahne 19cm	0009 01 0019 12 000000		193 (7.6)	21	356	6,82	8,87	10,91	12,96	15,00
Teller flach rund Fahne 21cm	0009 01 0021 12 000000		210 (8.27)	21	400	7,90	10,27	12,64	15,01	17,38
Teller flach rund Fahne 24cm	0009 01 0024 12 000000		242 (9.53)	27	540	10,21	13,27	16,34	19,40	22,46
Teller flach rund Fahne 26cm	0009 01 0026 12 000000		261 (10.28)	28	670	11,82	15,37	18,91	22,46	26,00
Teller flach rund Fahne 28cm	0009 01 0028 12 000000		278 (10.94)	27	805	13,97	18,16	22,35	26,54	30,73



Teller tief rund Fahne 23cm

Plate deep round with rim
Assiette creuse ronde avec aile
Plato hondo redondo con ala

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Teller tief rund Fahne 23cm	0009 01 0723 12 000000	0.42 (14.20)	234 (9.21)	38	525	10,21	13,27	16,34	19,40	22,46



Teller tief rund Fahne 23cm

Plate deep round with rim
Assiette creuse ronde avec aile
Plato hondo redondo con ala

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Teller tief rund Fahne 23cm	0009 01 0123 12 000000	0.35 (11.83)	235 (9.25)	39	570	10,21	13,27	16,34	19,40	22,46



Platte oval Fahne

Platter oval with rim
plat ovale avec aile
Fuente ovalada con ala

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Platte oval Fahne 26x18cm	0009 01 2026 12 000000		273 x 179 (10.75 x 7.05)	26	540	16,46	21,40	26,34	31,27	36,21
Platte oval Fahne 29x20cm	0009 01 2029 12 000000		303 x 197 (11.93 x 7.76)	29	725	19,36	25,17	30,98	36,78	42,59
Platte oval Fahne 33x23cm	0009 01 2033 12 000000		344 x 227 (13.54 x 8.94)	32	940	23,23	30,20	37,17	44,14	51,11
Platte oval Fahne 38x26cm	0009 01 2038 12 000000		384 x 255 (15.12 x 10.04)	33	1435	28,07	36,49	44,91	53,33	61,75

FORM 98



Suppenobertasse 0.25l

Creamsoup cup
Tasse à soupe
Taza para sopa



Untertasse rund 15cm

Saucer round
Soucoupe ronde
Platillo redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Suppenobertasse 0.25l	0009 01 2727 12 000000	0.25 (8.45)	100 (3.94)	50	185	8,00	10,40	12,80	15,20	17,60
Untertasse rund 15cm	0009 01 6927 12 000000		147 (5.79)	22	180	4,09	5,32	6,54	7,77	9,00



Suppenobertasse 0.30l

Creamsoup cup
Tasse à soupe
Taza para sopa



Untertasse rund 16cm

Saucer round
Soucoupe ronde
Platillo redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Suppenobertasse 0.30l	0009 01 2732 12 000000	0.30 (10.14)	108 (4.25)	52	230	8,65	11,25	13,84	16,44	19,03
Untertasse rund 16cm	0009 01 6930 12 000000		160 (6.3)	24	210	4,30	5,59	6,88	8,17	9,46



Obertasse 0.09l

Cup
Tasse
Taza



Untertasse rund 12cm

Saucer round
Soucoupe ronde
Platillo redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Obertasse 0.09l	0009 01 5359 12 000000	0.09 (3.04)	67 (2.64)	58	140	5,29	6,88	8,46	10,05	11,64
Untertasse rund 12cm	0009 01 6809 12 000000		120 (4.72)	18	105	3,44	4,47	5,50	6,54	7,57



Obertasse 0.25l

Cup
Tasse
Taza



Untertasse rund 15cm

Saucer round
Soucoupe ronde
Platillo redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Obertasse 0.25l	0009 01 5275 12 000000	0.26 (8.79)	90 (3.54)	84	255	7,36	9,57	11,78	13,98	16,19
Untertasse rund 15cm	0009 01 6922 12 000000		151 (5.94)	22	190	4,54	5,90	7,26	8,63	9,99



Obertasse 0.09l

Cup
Tasse
Taza



Untertasse rund 11cm

Saucer round
Soucoupe ronde
Platillo redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Obertasse 0.09l	0009 01 5259 12 000000	0.09 (3.04)	59 (2.32)	60	130	5,29	6,88	8,46	10,05	11,64
Untertasse rund 11cm	0009 01 6909 12 000000		110 (4.33)	15	110	3,23	4,20	5,17	6,14	7,11

FORM 98

 **Bowl rund**
Bowl round
Bol rond
Tazón redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Bowl rund 9cm/0.19l	0009 01 5469 12 000000	0.19 (6.42)	88 (3.46)	51	150	5,94	7,72	9,50	11,29	13,07
Bowl rund 10cm/0.25l	0009 01 5376 12 000000	0.25 (8.45)	97 (3.82)	57	185	6,71	8,72	10,74	12,75	14,76
Bowl rund 10cm/0.30l	0009 01 5380 12 000000	0.30 (10.14)	104 (4.09)	61	190	7,36	9,57	11,78	13,98	16,19
Bowl rund 11cm/0.40l	0009 01 5390 12 000000	0.40 (13.53)	114 (4.49)	64	255	8,65	11,25	13,84	16,44	19,03

 **Schale rund 13cm/0.20l**
Bowl round
Bol rond
Bowl redondo

 **Schüssel rund 16cm/0.41l**
Bowl round
Saladier rond
Bol redondo

 **Schüssel rund 18cm/0.60l**
Bowl round
Saladier rond
Bol redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Schale rund 13cm/0.20l	0009 01 3113 12 000000	0.20 (6.76)	134 (5.28)	31	200	6,71	8,72	10,74	12,75	14,76
Schüssel rund 16cm/0.41l	0009 01 3116 12 000000	0.41 (13.86)	160 (6.3)	41	306	8,78	11,41	14,05	16,68	19,32
Schüssel rund 18cm/0.60l	0009 01 3118 12 000000	0.60 (20.29)	183 (7.2)	46	385	11,23	14,60	17,97	21,34	24,71

 **Schale rund 14cm/0.50l**
Bowl round
Bol rond
Bowl redondo

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Schale rund 14cm/0.50l	0009 01 6650 12 000000	0.50 (16.91)	138 (5.43)	76	390	9,94	12,92	15,90	18,89	21,87

 **Terrine Komplet 28x21cm/2.40l**
Tureen
Terrine
Terrina

 **Terrine Unterteil 28x21cm/2.40l**
Tureen
Terrine
Terrina

 **Terrine Deckel**
Tureen
Terrine
Terrina

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Terrine Komplet 28x21cm/2.40l *	0009 01 3724 13 000000	2.40 (81.15)	275 x 210 (10.83 x 8.27)	150	1580	62,83	81,68	100,53	119,38	138,23
Terrine Unterteil 28x21cm/2.40l *	0009 01 3725 12 000000	2.40 (81.15)	275 x 210 (10.83 x 8.27)	115	1100	35,75	46,48	57,20	67,93	78,65
Terrine Deckel *	0009 01 3726 12 000000		198 (7.8)	44	480	27,08	35,20	43,33	51,45	59,58

 **Terrine**
Tureen
Terrine
Terrina

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Terrine 15cm/0.90l *	0009 01 3490 12 000000	0.90 (30.43)	147 (5.79)	85	590	16,39	21,31	26,22	31,14	36,06
Terrine 16cm/1.25l *	0009 01 3512 12 000000	1.25 (42.27)	163 (6.42)	93	740	20,91	27,18	33,46	39,73	46,00
Terrine 18cm/1.50l *	0009 01 3516 12 000000	1.50 (50.72)	176 (6.93)	102	990	24,13	31,37	38,61	45,85	53,09
Terrine 21cm/2.50l	0009 01 3525 12 000000	2.50 (84.54)	205 (8.07)	112	1350	37,04	48,15	59,26	70,38	81,49

*
Auslaufartikel zum 31.12.2026
Discontinued article as of 31/12/2026

FORM 98

 **Kaffeekanne**
Coffee pot
Cafetière
Cafetera

 **Kaffeekanne**
Coffee pot
Cafetière
Cafetera

 **Kaffeekanne**
Coffee pot
Cafetière
Cafetera

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Kaffeekanne Komplet 0.30l	0009 01 4130 13 000000	0.30 (10.14)	124 x 79 (4.88 x 3.11)	119	300	19,34	25,14	30,94	36,75	42,55
Kaffeekanne Unterteil 0.30l	0009 01 4131 12 000000	0.30 (10.14)	124 x 79 (4.88 x 3.11)	103	260	14,33	18,63	22,93	27,23	31,53
Kaffeekanne Deckel	0009 01 4132 12 000000		58 (2.28)	28	40	5,01	6,51	8,02	9,52	11,02
Kaffeekanne Komplet 0.60l	0009 01 4160 13 000000	0.60 (20.29)	155 x 96 (6.1 x 3.78)	147	530	30,94	40,22	49,50	58,79	68,07
Kaffeekanne Unterteil 0.60l	0009 01 4161 12 000000	0.60 (20.29)	155 x 96 (6.1 x 3.78)	127	455	22,92	29,80	36,67	43,55	50,42
Kaffeekanne Deckel	0009 01 4162 12 000000		73 (2.87)	33	75	8,02	10,43	12,83	15,24	17,64

 **Teekanne**
Teapot
Théière
Tetera

 **Teekanne**
Teapot
Théière
Tetera

 **Teekanne**
Teapot
Théière
Tetera

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Teekanne Komplet 0.40l	0009 01 4340 13 000000	0.40 (13.53)	165 x 110 (6.5 x 4.33)	95	633	23,21	30,17	37,14	44,10	51,06
Teekanne Unterteil 0.40l	0009 01 4341 12 000000	0.40 (13.53)	165 x 110 (6.5 x 4.33)	89	330	17,19	22,35	27,50	32,66	37,82
Teekanne Deckel	0009 01 4342 12 000000		84 (3.31)	34	83	6,02	7,83	9,63	11,44	13,24
Teekanne Komplet 0.80l	0009 01 4380 13 000000	0.80 (27.05)	190 x 125 (7.48 x 4.92)	115	710	38,69	50,30	61,90	73,51	85,12
Teekanne Unterteil 0.80l	0009 01 4381 12 000000	0.80 (27.05)	190 x 125 (7.48 x 4.92)	90	507	28,66	37,26	45,86	54,45	63,05
Teekanne Deckel	0009 01 4382 12 000000		102 (4.02)	39	145	10,03	13,04	16,05	19,06	22,07
Teekanne Komplet 1.10l	0009 01 4410 13 000000	1.10 (37.20)	227 x 147 (8.94 x 5.79)	127	950	50,29	65,38	80,46	95,55	110,64
Teekanne Unterteil 1.10l	0009 01 4411 12 000000	1.10 (37.20)	227 x 147 (8.94 x 5.79)	104	750	37,25	48,43	59,60	70,78	81,95
Teekanne Deckel	0009 01 4412 12 000000		119 (4.69)	40	200	13,04	16,95	20,86	24,78	28,69

 **Gießer**
Creamer
Crémier
Jarra

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Gießer 0.06l	0009 01 4706 12 000000	0.06 (2.03)	49 (1.93)	59	80	7,45	9,69	11,92	14,16	16,39
Gießer 0.10l	0009 01 4710 12 000000	0.10 (3.38)	54 (2.13)	69	106	8,60	11,18	13,76	16,34	18,92
Gießer 0.15l	0009 01 4715 12 000000	0.15 (5.07)	63 (2.48)	78	160	10,03	13,04	16,05	19,06	22,07
Gießer 0.25l	0009 01 4725 12 000000	0.25 (8.45)	76 (2.99)	93	260	12,90	16,77	20,64	24,51	28,38
Gießer 0.50l	0009 01 4750 12 000000	0.50 (16.91)	93 (3.66)	121	410	20,06	26,08	32,10	38,11	44,13
Gießer 1.00l	0009 01 4810 12 000000	1.00 (33.81)	112 (4.41)	149	670	34,39	44,71	55,02	65,34	75,66

 **Zuckerdose Komplet 0.30l**
Sugar bowl
Sucrier
Azucarero

 **Zuckerdose Unterteil 0.30l**
Sugar bowl
Sucrier
Azucarero

 **Zuckerdose Deckel**
Sugar bowl
Sucrier
Azucarero

	# Art.-Nr. (Art.No.)	Ltr. (fl.oz)	mm (inch)	mm	Gramm	Euro				
						Standard	Light	Basic	Basic+	Exclusive
Zuckerdose Komplet 0.30l	0009 01 4930 13 000000	0.30 (10.14)	99 (3.9)	79	305	12,89	16,76	20,62	24,49	28,36
Zuckerdose Unterteil 0.30l	0009 01 4931 12 000000	0.30 (10.14)	99 (3.9)	64	240	7,36	9,57	11,78	13,98	16,19
Zuckerdose Deckel	0009 01 4932 12 000000		79 (3.11)	25	52	5,53	7,19	8,85	10,51	12,17

FORM 98

Teller flach rund Fahne, Plate flat round with rim

15 cm
9 01 0615 1



115 mm
155 mm

17 cm
9 01 0617 1



133 mm
179 mm

19 cm
9 01 0619 1




144 mm
194 mm

23 cm
9 01 0623 1



187 mm
236 mm

26 cm
9 01 0626 1



213 mm
255 mm

Teller flach rund Fahne, Plate flat round with rim

15 cm
9 01 0015 1



96 mm
150 mm

17 cm
9 01 0017 1



110 mm
173 mm

19 cm
9 01 0019 1



125 mm
193 mm

21 cm
9 01 0021 1



137 mm
210 mm

24 cm
9 01 0024 1



168 mm
242 mm

26 cm
9 01 0026 1



170 mm
261 mm

28 cm
9 01 0028 1



191 mm
278 mm

Teller tief rund Fahne, Plate deep round with rim

23 cm
9 01 0723 1



175 mm
234 mm

23 cm
9 01 0123 1



160 mm
235 mm

Teller tief rund Fahne, Plate deep round with rim

FORM 98

Platte oval Fahne, Platter oval with rim

26x18 cm
9 01 2026 1




230 x 136 mm
273 mm

29x20 cm
9 01 2029 1



252 x 150 mm
303 mm

33x23 cm
9 01 2033 1



290 x 172 mm
344 mm

38x26 cm
9 01 2038 1



318 x 190 mm
384 mm

Untertasse rund, Saucer round

15 cm
9 01 6927 1



61 mm
147 mm

16 cm
9 01 6930 1



68 mm
160 mm

Untertasse rund, Saucer round

12 cm
9 03 6909 1



36 mm
120 mm

Untertasse rund, Saucer round

11 cm
9 11 6909 1



43 mm
111 mm