



PERFECT MATCH - Breeze



Teller flach rund coup /
Plate flat round coupe
breeze 15cm

0008 01 1215 41 000100
Ø15cm / Ø5.91"
-
210 g
2cm / 0.79"
6
7,21 €



Teller flach rund coup /
Plate flat round coupe
breeze 21cm

0008 01 1221 41 000100
Ø21cm / Ø8.27"
-
420 g
2.3cm / 0.91"
6
10,73 €



Teller flach rund coup /
Plate flat round coupe
breeze 27cm

0008 01 1227 41 000100
Ø26.8cm / Ø10.55"
-
750 g
2.7cm / 1.06"
6
17,22 €



Teller tief hoher Rand /
Plate deep high rim
breeze 24cm

0008 01 1924 41 000100
Ø24cm / Ø9.45"
115l / 38.89oz
1040 g
4.5cm / 1.77"
6
27,18 €



Platte oval coup /
Platter oval coupe
breeze 25x19cm

0008 01 2225 41 000100
25.3cm x 19cm / 9.96" x 7.48"
-
630 g
2.6cm / 1.02"
6
21,57 €



Platte oval coup /
Platter oval coupe
breeze 31x24cm

0008 01 2231 41 000100
30.8cm x 24cm / 12.13" x 9.45"
-
1030 g
2.8cm / 1.1"
6
28,05 €



Teller flach rund coup /
Plate flat round coupe
breeze 30cm

0008 01 1230 41 000100
Ø30.1cm / Ø11.85"
-
970 g
3.2cm / 1.26"
6
25,48 €



Teller tief rund coup /
Plate deep round coupe
breeze 23cm

0008 01 1323 41 000100
Ø23.2cm / Ø9.13"
1.00l / 33.81oz
520 g
4.5cm / 1.77"
6
16,73 €



Teller tief rund coup /
Plate deep round coupe
breeze 28cm

0008 01 1328 41 000100
Ø28cm / Ø11.02"
-
927 g
5.3cm / 2.09"
6
20,19 €



Platte oval coup /
Platter oval coupe
breeze 36x28cm

0008 01 2236 41 000100
36cm x 28cm / 14.17" x 11.02"
-
1310 g
2.9cm / 1.14"
6
40,16 €



Schälchen rund /
Small dish round
breeze 8cm/0.06l

0008 01 6108 41 000100
Ø8.1cm / Ø3.19"
0.06l / 2.03oz
90 g
2.3cm / 0.91"
12
6,28 €



Schälchen rund /
Small dish round
breeze 10cm/0.25l

0008 01 5710 41 000100
Ø10.3cm / Ø4.06"
0.25l / 8.45oz
220 g
6cm / 2.36"
6
7,65 €



Teller flach rund hoher Rand /
Plate round flat high rim
breeze 21cm

0008 01 1821 41 000100
Ø21.4cm / Ø8.43"
0.40l / 13.53oz
570 g
2.3cm / 0.91"
6
18,54 €



Teller flach rund hoher Rand /
Plate round flat high rim
breeze 27cm

0008 01 1827 41 000100
Ø26.7cm / Ø10.51"
0.60l / 20.29oz
860 g
2.2cm / 0.87"
6
24,31 €



Teller tief hoher Rand /
Plate deep high rim
breeze 20cm

0008 01 1921 41 000100
Ø20cm / Ø7.87"
0.85l / 28.74oz
740 g
4.5cm / 1.77"
6
21,02 €



Schale rund /
Bowl round
breeze 14cm/0.60l

0008 01 5714 41 000100
Ø14.4cm / Ø5.67"
0.60l / 20.29oz
410 g
7.2cm / 2.83"
6
11,61 €



Schüssel rund /
Bowl round
breeze 19cm/0.90l

0008 01 5719 41 000100
Ø19cm / Ø7.48"
0.90l / 30.43oz
567 g
6.4cm / 2.52"
6
17,44 €



Schüssel rund /
Bowl round
breeze 23cm/1.50l

0008 01 5723 41 000100
Ø23cm / Ø9.06"
1.50l / 50.72oz
755 g
7cm / 2.76"
6
24,43 €





Obertasse /
Cup
breeze 0.08l

0008 01 5258 41 000100
Ø6cm / Ø2.36"
0.08l / 2.71oz
109 g
6cm / 2.36"
6
5,06 €



Untertasse rund /
Saucer round
breeze 12cm

0008 01 6908 41 000100
Ø12cm / Ø4.72"
-
113 g
1.8cm / 0.71"
6
4,41 €



Obertasse /
Cup
breeze 0.25l

0008 01 5271 41 000100
Ø9cm / Ø3.54"
0.25l / 8.45oz
210 g
7cm / 2.76"
6
5,83 €



Untertasse rund /
Saucer round
breeze 14cm

0008 01 6921 41 000100
Ø14cm / Ø5.51"
-
233 g
2cm / 0.79"
6
5,17 €



Obertasse /
Cup
breeze 0.35l

0008 01 5284 41 000100
Ø11cm / Ø4.33"
0.35l / 11.83oz
340 g
7.2cm / 2.83"
6
7,15 €



Untertasse rund /
Saucer round
breeze 16cm

0008 01 6934 41 000100
Ø15.5cm / Ø6.1"
-
262 g
2.2cm / 0.87"
6
5,72 €



Becher /
Mug
breeze 0.27l

0008 01 5625 41 000100
Ø7.5cm / Ø2.95"
0.27l / 9.13oz
340 g
9.5cm / 3.74"
6
7,15 €

